



- NOTES:
1. SAMPLING SUMP SHALL BE LOCATED DIRECTLY BELOW MANHOLE ACCESS.
 2. FLUME AND FLOWMETER SHALL NOT BE LOCATED BELOW MANHOLE ACCESS OR OBSTRUCT INSTALLATION OF SAMPLING EQUIPMENT.
 3. INSTALLING CONTRACTOR SHALL BE RESPONSIBLE FOR PROPER SLOPE AND CONSTRUCTION OF CONNECTING PIPELINE.
 4. INSTALLING CONTRACTOR SHALL BE RESPONSIBLE FOR PROTECTION OF EXISTING SEWER AND OTHER UTILITIES, PROPER BACKFILLING, COMPACTING, AND PAVEMENT RESTORATION.
 5. CONTRACTOR SHALL NOTIFY DISTRICT 24 HOURS BEFORE INSTALLATION BEGINS.
 6. CONTRACTOR SHALL GUARANTEE WORK FOR A PERIOD OF ONE YEAR.



Figure 7-3
NORTH DAVIS SEWER DISTRICT
Industrial Pretreatment Program
Standard Sampling Manhole